

Virex[®]II 256 One-Step Disinfectant Cleaner and Deodorant



A one-step, quaternary disinfectant cleaner and deodorant to clean and disinfect hard surfaces.

Broad Spectrum Activity

- Kills microorganisms including HIV-1, VRE, MRSA, GRSA, MRSE, VISA, PRSP, Herpes Simplex Types 1&2, Influenza Type A2, Adenovirus Type 2, Rotavirus and many more
- Meets OSHA bloodborne pathogen standards

Cost-Effective

 Highly concentrated quaternary formula provides excellent one-step, cost-effective cleaning and disinfection

No Rinse Formula

 Use solution is neutral to floor finish so it will not dull, pit or soften floor finishes

Odor Control

 Kills the organisms that cause odors and works as an odor counteractant to further eliminate odors not associated with bacteria

Designed For

- Health Care
- Education
- Retail
- BSC
- Government
- Lodging



Use Overview

Virex[®] Il 256 is a one-step disinfectant cleaner and deodorant. For use on hard, inanimate, nonporous surfaces such as floors, walls, porcelain and plastic surfaces in hospitals, nursing homes, schools, colleges and hotels.

- Add the product at ½ oz. per gallon of water (1:256).
- Pre-clean heavily soiled areas.

For Use as a One-Step Cleaner/Disinfectant

Apply use solution to hard, non-porous environmental surfaces. To disinfect, all surfaces must remain wet for 10 minutes.

Note: Rinsing is not necessary unless floors are to be coated with finish or restorer. All food contact surfaces such as appliances and kitchen countertops must be rinsed with potable water. Do not use on glassware, utensils or dishes.

For Use as a Cleaner and Deodorizer

Concentrate

70627-24

0%

Minty

Concentrate

Flammability

Use Dilution 1:256

Reactivity

Health

Flammability

Health

>187° F (> 86.1° C)

10.2 (Concentrate) 8.8 (Use Dilution)

36 months (Concentrate) 1 year (Use Dilution)

Apply use solution to surfaces. Wipe surfaces and let air dry.

For Use as a Non-Acid Bowl Cleaner/Disinfectant in Toilet Bowls and Urinals from Use-Dilution

Empty toilet bowls by forcing water through the trap. Apply use

Transparent blue liquid

Product Specifications

Description Color/Form

EPA Reg. No.

Flash Point

Phosphates

pН

Scent

HMIS

3

1

0

1

0

HMIS

Shelf Life

Hazard Rating

Available Items

			1000		1.1.1	52 L
10 m	The second	1.5 1.6	and sur-	E Statistics	\$5.55 m	
	10000	10.00	22	10.000	10.00	-
			100	And in case of the local division of the loc		

solution to exposed surfaces in toilet bowls and urinals. Swab entire surface area especially under rim. Allow entire surface to remain wet for 10 minutes. Flush toilet or urinal and rinse swab applicator thoroughly.

For Use to Clean and Disinfect Shower Rooms, Locker Rooms and Other Large, Open Areas with Floor Drains

Apply use solution to floors, walls and ceilings. All surfaces must remain wet for 10 minutes. Scrub and rinse surfaces thoroughly and let air dry.

To Kill Mold, Mildew and Fungi (in 5% soil load)

 Apply use solution and allow surfaces to remain wet for 10 minutes. Wipe and let air dry.

To Control Mold and Mildew

 Apply use solution to pre-cleaned surfaces and allow to air dry. Repeat weekly or when growth reappears.

Available ite	ems	
Product Code	Description/Package Size	Dilution
3062637	2 x 1.5 L / 1.59 Qt. RTD® Units	1:256
3062768	1 x 5 L / 1.32 gallon RTD® Unit	1:256
04329	2 x 2.5 L / 84.5 oz. J-Fill® Bottles	1:256
04337	4 x 64 oz. / 1.89 L Solutions Center® Bottles	1:256
04331	6 x 32 oz. / 946 mL AccuMix® Containers	1:256
04332	4 x 1 gallon / 3.78 L Containers	1:256
5019317	2 x 1.4 L / 1.48 Qt. SmartDose [™] Bottles	1:256 (Spray Bottle), 1:256 (Mop Bucket)
5271416	2 x 1.5 gallon / 5.67 L Command Center® Units	1:256
5295291	2 x 3 L / 3.17 Qt. Outpost® Units	1:256
03916	12 x 32 fl . oz. / 946 mL Spray Bottles	

Safety Reminder

Please make sure your employees read and understand the product label and Material Safety Data Sheet before using this product. The label contains directions for use, and both the label and MSDS contain hazard warnings, precautionary statements and first aid procedures. MSDS are available on-line at www.diversey.com or by calling 888 352 2249.

SmartDose[™] lcons





0	Reactivity	0				
4=Very High; 3=High; 2=Moderate; 1=Slight; 0=Insignificant.						

For additional information, please contact us at +1 800 558 2332 or at www.diversey.com © 2012 Diversey, Inc., 8310 16th Street, Sturtevant, WI 53177-1964. All Rights Reserved. SPC064 (12/061)

NFPA

3

1

0

1

0

NFPA